

knot too shabby

Painting The "Annie Sloan" way

Tips for Painting with the best Paint on Planet Earth

Annie Sloan Chalk Paint

1. Paint your Furniture—no priming no sanding required. Most pieces only require one coat of paint. Apply a light second coat if needed.
 2. When paint is dry, add distressing with a warm wet cloth or fine sandpaper or sanding block. I recommend 220 grit.
 3. After desired distressing, add a thin coat of clear wax over entire surface. Wipe off excess wax.*
 4. Add dark wax to desired areas. Wipe off excess wax with cloth. Use clear wax to "erase" the dark wax where too much was applied. Wipe off excess wax.
 5. After wax is applied, wait 24 hours then buff entire piece with a cloth or soft brush.
- *Always remember to apply clear wax before dark wax**
**The exception is if you are painting with graphite. Dark wax is applied directly on top of the paint.

Don't hesitate to call us with your painting questions! We'll be more than happy to help!

(626) 914-1600

knottooshabbyglendora@gmail.com

